



JackHammers.com


1-800-241-9669

Chicago Pneumatic reference | Tools, parts & expert help

Spare parts list

Pneumatic scabbler

CP 0006, CP 0006 SVR



JackHammers.com



JackHammers.com

Tools, parts & expert help

1-800-241-9669

Call for model and parts matching



Contents

General information 5

Spare parts list 6

 CP 0006..... 6

 CP 0006 SVR..... 8

Accessories 10

 Hose rolls..... 10

 Pre-mounted universal hoses with claw couplings..... 10

 Water separator..... 11





General information

This spare parts list applies to the following:

Description

Pneumatic scabbler CP 0006

Pneumatic scabbler CP 0006 SVR

Use only authorized parts. Any damage or malfunction caused by the use of unauthorized parts is not covered by Warranty or Product Liability. Any unauthorized use or copying of the contents or any part thereof is prohibited. This applies in particular to trademarks, model denominations, part numbers, and drawings.

Instructions for use

This spare parts list contains no safety regulations and is merely intended to assist in the ordering of spare parts.


For information about operating, servicing, or repairing, the relevant Safety and operating instructions must be consulted at all costs.

Please observe the safety instructions listed in the relevant Safety and operating instructions!



Spare parts list


CP 0006



No.	Description	Remark	Quantity	Part number
1	Cap screw	Socket head	4	F826516
2	Handle - Cylinder		1	F826708
3	O-ring		3	A082759
4	Ball valve		3	F061776
5	Cylinder cap		3	F826706
6	Piston		3	F064604
7(8-9)	Cylinder, complete		1	F826707
8	Cylinder bushing		3	F826808
9	Cylinder		1	-
10	Locknut		2	F064909
11	Handle - Bent		1	F064668
12	Bushing - Reducer		1	F826506
13(14-15,16,19,22-23)	Throttle body, complete		1	P007395
14	Pin - Lever		1	P001921
15	Lever - Throttle		1	P001903
16(17-18)	Body - Throttle, complete		1	P007350
17	Body - Throttle		1	-
18	Throttle valve bushing		1	P001814
19(20-21)	Throttle valve, complete		1	P087671
20	Throttle valve		1	-
21	O-ring		1	CA088867
22	Spring		1	P001858
23	Cap valve screw		1	P001964
24	Strainer - Air		1	P001995
25	Data plate		1	-
26	Drive screw		2	0244 4144 00
27	Safety label		1	3310 1602 00



CP 0006 SVR



No.	Description	Remark	Quantity	Part number
1(2-3)	Cylinder, complete		1	3303 0052 41
2	Cylinder		1	-
3	Cylinder bushing		3	F826808
4	Piston		3	F064604
5	Cylinder cap		3	F826706
6	Ball valve		3	F061776
7	O-ring		3	A082759
8	Cylinder cover		1	3303 0051 92
9	Cap screw	Socket head	4	F826516
10	Pin - lever		2	P001921
11	Adaptor bolt		1	3303 0051 93
12(13)	Bearing ball, complete	15 balls included	1	3303 0052 42
13	Bearing ball	1½ in.	15	-
14	Pin		1	3121 0595 00
15	Locknut		2	F064909
16	Handle - Bent pipe		1	3303 0051 94
17(18-20)	Throttle body, complete		1	3303 0052 45
18	Throttle body		1	-
19	Throttle handle grip		1	3303 0052 01
20	Throttle valve bushing		1	P001814
21	Air inlet nipple	½ in. BSP	1	3303 0052 04
22(23-24)	Body valve, complete		1	3303 0052 44
23	Body valve		1	-
24	O-ring		1	P088844
25	Spring		1	P001858
26	Cap valve screw		1	P001964
27	Throttle valve lever		1	3303 0052 02
28	Handle bow		1	3303 0052 03
29	Bracket		1	3303 0051 95
30	Front handle		1	3303 0052 38
31	Bushing		1	3303 0051 96
32	Screw	¼ in.	1	0211 5209 00
33(34-35)	Handle bar, complete		1	3303 0052 43
34	Handle bar		1	-
35	Front handle grip		1	3303 0052 00
36	Hexagon screw	¼ in.	2	0144 3205 00
37	Data plate		1	-
38	Drive screw		2	0244 4144 00
39	Hexagon screw		1	0147 1444 03
40	Locknut		1	0291 1128 41
41	Safety label		1	3310 1602 00
42	Air inlet nipple	optional, ½ in. NPTF	1	3303 0052 20



Accessories

Hose rolls

Metric

Description	Inner diameter (mm)	Thickness (mm)	Maximum working pressure (bar)	Length of roll (m)	Weight (kg)	Part number
Red-X hose roll	19	2.0	20	60	11	8900 0050 10
Red-X hose roll	19	2.0	20	100	18	8900 0050 11
Red-X hose roll	19	2.0	20	200	36	8900 0050 12
Red-X hose roll	25	2.5	20	60	15	8900 0050 20
Red-X hose roll	25	2.5	20	100	25	8900 0050 21
Red-X hose roll	25	2.5	20	200	50	8900 0050 22

Imperial

Description	Inner diameter (in.)	Thickness (in.)	Maximum working pressure (psi)	Length of roll (ft)	Weight (lb)	Part number
Red-X hose roll	$\frac{3}{4}$	$\frac{5}{64}$	290	195	24.3	8900 0050 10
Red-X hose roll	$\frac{3}{4}$	$\frac{5}{64}$	290	325	39.7	8900 0050 11
Red-X hose roll	$\frac{3}{4}$	$\frac{5}{64}$	290	650	79.4	8900 0050 12
Red-X hose roll	1	$\frac{3}{32}$	290	195	33.1	8900 0050 20
Red-X hose roll	1	$\frac{3}{32}$	290	325	55.1	8900 0050 21
Red-X hose roll	1	$\frac{3}{32}$	290	650	110.2	8900 0050 22

Pre-mounted universal hoses with claw couplings

Metric

Description	Inner diameter (mm)	Thickness (mm)	Maximum working pressure (bar)	Length of roll (m)	Weight (kg)	Part number
Red-X universal hose	19	2.0	20	20	4.5	8900 0050 09
Red-X universal hose	25	2.5	20	20	6.0	8900 0050 23

Imperial

Description	Inner diameter (in.)	Thickness (in.)	Maximum working pressure (psi)	Length of roll (ft)	Weight (lb)	Part number
Red-X universal hose	$\frac{3}{4}$	$\frac{5}{64}$	290	50	8.8	8900 0050 08
Red-X universal hose	1	$\frac{3}{32}$	290	50	11.0	8900 0050 24



Water separator

Metric

Description	Hose connection (mm)	Air flow (l/s)	Weight (kg)	Part number
Water separator (¾ in. BSP)	20	61	0.8	8900 0050 00

Imperial

Description	Hose connection (in.)	Air flow (foot ³ /min)	Weight (lb)	Part number
Water separator (¾ in. NPT)	¾	130	1.8	8900 0050 01











JackHammers.com

1-800-241-9669

Chicago Pneumatic reference | Tools, parts & expert help

2010-12 | No. 9800 0534 01b

© Copyright Atlas Copco Construction Tools AB | STOCKHOLM • SWEDEN



JackHammers.com

Tools, parts & expert help

1-800-241-9669

Call for model and parts matching